

Input the gear ratio of the gearbox to use.

※ RPM to indicate is calculated by motor pole number and gear ratio.

12 Indication of maximum RPM

MAXIMUM RPM
000000 RPM ± Air

The maximum RPM during the last flight is indicated.

※ RPM to indicate is calculated by motor pole number and gear ratio. Default is test value when the ESC leaves the factory. It changes when the motor is run.

13 Indication of average RPM

AVERAGE RPM
000000 RPM ± Air

The average RPM during the last flight is indicated.

※ RPM to indicate is calculated by motor pole number and gear ratio. Default is test value when the ESC leaves the factory. It changes when the motor is run.

14 Download the set data to the ESC

DOWN LOAD
Really? No ± Air

This is to write (transfer) the set values to the ESC. Press INC(+) to start writing.

※ Beep once every second continues until the writing is completed. If you want to quit in the middle, press DEC(-).

15 Access to the stored data in the programmer

RESTORE MEMORY
Really? No ± Air

This is to access the stored data in the programmer. Press INC(+) to start the process.

※ Beep once every second continues until the process is completed. If you want to quit in the middle, press DEC(-).

16 Storing the set data in the programmer's memory

BACKUP MEMORY
Really? No ± Air

This is to store the set data in the programmer's memory. Press INC(+) to start the process.

※ Beep once every second continues until the process is completed. If you want to quit in the middle, press DEC(-).

RECOMMENDED MOTOR/ESC BY MODEL CLASS

Class	Motors		Recommended ESCs
10~30	OMA-3805-1200 OMA-3815-1000 OMA-3820-1200	OMA-3810-1050 OMA-3820-960 OMA-3825-750	OCA-150
30~70	OMA-3825-750	OMA-5020-490	OCA-150~ OCA-170HV
70~91	OMA-5010-810 OMA-5025-375	OMA-5020-490	OCA-170HV~ OCA-1100HV

Note

Some using combination of cell number and propeller size may flow the current more than ESC's capacity. Refer to the instruction manual and propeller data listing supplied with the O.S. motor.

SPECIFICATIONS

	OCA-170HV	OCA-1100HV
Function	Forward-Stop-Brake-Reverse	
Working voltage range	14.8~50.4V	
Load current (Peak)	70A (85A 5 seconds)	100A (150A 5 seconds)
Size	78x29x14mm	73.4x56x31mm
Weight	89g	124g
Cell number	14-36 NiCd/NiMH, 4-12 LiPo	
Parameter setting	ESC/ESC Programmer OCP-1 (Optional extra)	
Protective function	Start protection/Low voltage cut-off/No signal cut-off/Overheat protection	
PWM Frequency	32kHz	

※ Cool Power FET: Latest generation power FET

※ Opto: Galvanic separation of the motor interference and receiver.

※ ESC Programmer OPC-1: By connecting to OCA-1100HV/OCA-170HV, detailed setting can be done easily.

※ Start protection: Stops involuntary starting of the motor.

※ Low voltage cut-off: Stops the motor before the voltage reaches the level where control is lost and potential over-discharge damage to the cells occurs.

※ No signal cut-off: Switches the ESC OFF when signal from the transmitter is not received.

※ Overheat protection: When the temperature rises extraordinary due to overload, restrict output to protect the ESC.

※ Anti-spark: Function to reduce sparks which occur when connecting power battery.

※ Battery cell number auto recognition: Function to recognize automatically cell number of the battery to connect.

● Pay careful attention to the advices with the following headings.

⚠ DANGER

This covers the possibility which might involve death and serious injury.

⚠ WARNINGS

These cover the possibilities which might involve death and serious injury and also may cause damage or injury.

⚠ NOTES

These cover the many other possibilities, generally less obvious source of danger, but which, under certain circumstances, may also cause danger or injury.

Graphic symbols: ⚡ ; Prohibited items ⚡ ; Items never fail to take action

O.S. ENGINES MFG. CO., LTD.
URL : <http://www.os-engines.co.jp>

6-15 3-Chome Imagawa Higashiumiyoshi-ku
Osaka 546-0003, Japan TEL. (06) 6702-0225
FAX. (06) 6704-2722

© Copyright 2011 by O.S. Engines Mfg. Co., Ltd. All rights reserved. 071200

O.S. ENGINE

IMPORTANT: It is of vital importance, before attempting to operate your OCA-170HV and OCA-1100HV to read through this instruction manual.

BRUSHLESS MOTOR ESC
FOR AIRPLANES

OCA-1100HV
OCA-170HV



INSTRUCTION MANUAL

● Concerning the recommended motor/ESC according to the model size, refer to the listing shown later part of the manual.

The OCA-170HV and OCA-1100HV are ESCs installed with the latest FET for brushless motors. By combining with separately available O.S. brushless motors, both ESC and motor develop their maximum performance.

● Before operating OCA-170HV and OCA-1100HV

※ Misuse or abuse of LiPo batteries is very dangerous. Be sure to follow the instruction manual supplied with the batteries.

※ Some commercially available motors will not match the advance adjustment of the OCA-170HV and OCA-1100HV. It is suggested to use them combining with the O.S. motors listed.

※ Be sure to install the connectors which match the batteries, securely soldering to the battery connecting wires of the ESC. Never use the ESC with the connectors temporarily connected.

Notes on installation

⚠ WARNINGS

⚡ Never use the OCA-170HV and OCA-1100HV beyond the working conditions listed in the specifications listing.

⚡ Do not mistake the polarity of the batteries.

※ Reverse connection may cause fire and ESC will be damaged or be burnt instantly.

⚡ Never short out any place of the ESC, batteries, motor, receiver and connectors.

※ Short circuit may cause fire and ESC will be damaged or be burnt instantly.

※ Be sure to install the ESC so that the soldering connection of the input/output wires may not touch conductive part.

⚡ Be sure to install the receiver and receiver antenna away from the place where high current flows such as ESC, motor wires, battery wires, power batteries.

※ Malfunction of the receiver due to noise will cause to lose model control which is very dangerous.

⚡ Be sure to insert connectors all the way securely.

※ Disconnection due to vibration may cause to lose model control which is very dangerous.

⚡ Be sure to install the ESC so that oil, grease and water may not come in contact with the ESC.

⚡ Be sure to install the ESC at the place where there is plenty of air flow for cooling.

⚡ Do not wrap the ESC with aluminum foil, etc.

※ Wrapping may spoil cooling effect and the ESC may not develop its original performance.

⚡ Be sure to install the motor securely and fix all the wires.

⚠ NOTE

⚡ Do not disassemble. Do not open the ESC case.

※ Opening of the case may cause damage inside components and render it irreparable.

Notes on operation

⚠ WARNINGS

⚡ Never touch or allow any part of the body to come into contact with any rotating part while operating.

※ Sudden rotating may cause serious injury.

※ Be careful with some receivers the motor may rotate for a moment when the power puts on.

⚡ Do not fly when rainy.

※ Entry of water drops into the ESC may cause malfunction and out of model control which is very dangerous. Also, it will cause failure. If malfunction is detected due to entry of water drops, send the ESC to the manufacturer or its distributor in each country for inspection and repair.

⚡ Be sure to follow the procedures mentioned below as to ON and OFF of the power switch.

● ON: Hold the throttle stick at stop position. Switch on the transmitter then receiver power.

● OFF: Hold the throttle stick at stop position. Switch off the receiver then transmitter power.

※ With reverse procedure propeller may rotate suddenly, which is very dangerous.

⚡ Be sure to remove the batteries when not in use.

※ Accidental switching on may cause sudden rotating of propeller or cause fire, which is very dangerous.

⚡ Be sure to check the ESC and all the movements of model controls before attempting flight.

※ Incorrect settings or using of unsuitable model may cause to lose model control which is very dangerous.

⚠ NOTE

⚡ Do not touch the motor nor ESC right after flight.


※ Touching them may cause burn.

HOW TO CONNECT THE OCA-1100HV/OCA-170HV

[PREPARATION]

Solder the corresponding battery connector to the battery connection wires of the ESC. Also, use a heat-shrink tube to isolate the connection. Solder the corresponding connectors (female) to the motor connection wires of the ESC. Also, use a heat-shrink tube to isolate the connection.

Connections of the OCA-1100HV are shown below. In case of the OCA-170HV, make connections in the same way.



SETTING OF THROTTLE POSITIONS

Set the high point and the slowest point as follows.
(In case of model type AIR)

Preparation

As explained before, connect the ESC, receiver (receiver battery is required) and motor. **Do not connect power battery at this time.**

Preparation

Set the throw angle of the throttle channel on the transmitter 100%. **In case of Futaba, set the reverse function of the throttle channel to the reverse.**

Procedure	Stick	LED
① Power the transmitter on and hold the throttle stick at full high.		----
↓		
② Connect the power battery. ● 10 seconds after a short beep, a double beep is emitted.	K	Lights up
↓		
③ Within 3 seconds after the step ②, fully pull down the throttle stick. ● After a short beep, a double beep is transmitted.	K	Lights up
↓		
④ Disconnect the power battery.		

※ When the LED on the ESC flashes, reverse the throttle channel using the servo reverse function on the transmitter. Disconnect the power battery and repeat the procedure from the beginning.

※ In case of model type CAR or BOAT and reverse function ON, step ③ should be replaced with the following.

Set the throttle stick neutral (a short beep)→reverse(a short beep)→(a double beep)→disconnect power battery to set high point, neutral point and reverse point.

SETTING OF PARAMETERS

Five parameters can be set without using the programmer in the following manner.

No.	Parameter type	When selecting the parameter	When checking and changing the parameter	
		LED/Beep	LED Lights up/ Beep (every 2 seconds)	LED flashes/ Beep (every 0.5 seconds)
1	Battery type	One flash/Beep (continues)	LiPo	NiCd/NiMH
2	Direction of motor rotation	Two flashes/Beeps (continues)	Normal	Reverse
3	Brake ON/OFF (AIR) Governor ON/OFF (HELI) Reverse ON/OFF (BOAT/CAR)	Three flashes/Beeps (continues)	OFF	ON
4	Model type	Four flashes/Beeps (continues)	AIR	HELI
5	Model type	Five flashes/Beeps (continues)	BOAT	CAR

(IMPORTANT) After setting model type at No.4 or No.5, do not check the setting, or the different model type will be overwritten.

How to select parameter type (number).

Select the parameter type (number) with the following procedure.

Preparation

As explained before, connect the ESC, receiver (receiver battery is required) and motor. **Do not connect power battery at this time.**

Procedure	Stick	LED
① Switch the receiver on and hold the throttle stick at full high position.		----
↓		
② Connect the power battery. ● 10 seconds after a short beep, a double beep is emitted and after 3 seconds a long double beep is emitted. ● Then, very short beep continues. (This confirms the parameter No.1 is selected.)	K	Lights up
↓		
③ Move the throttle stick quickly high→slow→high. ● Very short double beep continues. (This confirms the parameter No.2 is selected.)	K	Flashes
↓		
By repeating step ③, parameter No.3 (to be confirmed by very short triple beep) through parameter No.5 (to be confirmed by very short quintuple beep) can be selected.		

How to change parameter.

After selecting the parameter No. as explained above, change the parameter with the following procedure.

Procedure	Stick	LED
(Parameter to check or change is being selected.)	K	Flashes
↓		
① Hold the throttle stick at the slowest position. ● After 3 seconds, a beep is emitted. ● Then, LED and beep show the current setting.	K	Lights up or Flashes
↓		
(to change the current setting) ② Move the throttle stick quickly slow→high→slow. ● LED indication and beep change to confirm setting changed.	K	Lights up or Flashes
↓		
(to return to parameter No. selection) ② Move the throttle stick to full high position. ● A double beep is emitted to confirm returned to parameter selection.	K	Flashes
↓		
③ Disconnect the power battery ● Setting is saved.		

INITIAL SETTING

The following example explains how to set initial setting to use air brake.

SETTING OF THROTTLE POSITIONS

Store full high and slowest positions of the throttle stick in the ESC.

※ Follow the SETTING OF THROTTLE POSITIONS procedure explained before.

SETTING OF PARAMETERS

Set each parameter of the ESC according to the using conditions.

(IMPORTANT)

With the OCA-1100HV and OCA-170HV, model type AIR is stored as default. If setting is changed to a different model type, first select model type AIR and make each setting.

SELECTION OF BATTERY TYPE (Parameter No.1)

Select according to the type of power battery to use.

LiPo: LiPo battery

NiCd/NiMH: NiCd battery or Nickel-metal hydride battery

ON/OFF OF AIR BRAKE (Parameter No.3)

To use air brake function, set ON.

※ Set each parameter following the SETTING OF PARAMETERS explained before.

※ Detailed setting of parameter can be set using the optional extra ESC Programmer OCP-1.

After completing the initial setting, disconnect the power battery.

NORMAL OPERATION

WARNINGS

Be sure to set the parameters according to the throttle positions and using conditions before using the OCA-1100HV and OCA-170HV.

When normal operation is ready, check the direction of motor rotation. If the rotation is reverse, correct it by re-setting of the parameter or changing connection of the motor.

※ Wrong setting may cause sudden rotation of the motor or out of model control which is very dangerous.

In normal operation, connect the power battery with the throttle stick at the slowest position. After hearing a set of very short and short beep, you can operate the ESC. At this time, LED lights up.

※ If the power battery is connected with the throttle stick not at the slowest position, LED flashes. In this case, move the throttle stick to the slowest position and a set of very short and short beep is emitted to confirm ready to operate.

※ If the power battery is connected with the throttle stick at high and entered into the setting mode, disconnect the power battery and repeat from the beginning.

SETTINGS USING ESC PROGRAMMER OCP-1

By using an optional extra ESC Programmer OCP-1, settings of ESC can be programmed quickly and securely to meet model's specific requirements.



Editing Buttons

Connection of the programmer

Connect the OCP-1, power battery and motor to OCA-1100HV or OCA-170HV as explained before.

Operation of editing buttons

Selection of setting item	Select setting parameter with outer arrow buttons (↓ or ↑).
Change of setting	Use inner INC(+) and DEC(-) buttons to select setting or change setting.
Change of model type	You can change model type by pressing both arrow buttons at the same time.

Setting items

Items can be programmed with the OCP-1 are listed below.

Setting Item (Model type: AIR)	
① Selection of battery type	⑨ Air brake ON/OFF
② Setting of cut off voltage	⑩ Setting of motor pole number
③ Selection of cut off type	⑪ Setting of gear ratio
④ Selection of motor rotating direction	⑫ Indication of maximum RPM
⑤ Setting of advance timing	⑬ Indication of average RPM
⑥ Setting of acceleration	⑭ Down load the set data to the ESC
⑦ Setting of start power	⑮ Access to the stored data in the programmer
⑧ Selection of air brake type	⑯ Storing the set data in the programmer's memory

How to set

When the OCP-1 and power battery are connected to the ESC, current settings of the ESC are automatically stored in the OCP-1.

Select the item to change with the arrow buttons (↓ or ↑) and change the setting with INC(+) and DEC(-) buttons.

(IMPORTANT)

When the parameter setting of the ESC with the OCP-1 is completed, write the set data to the ESC with "⑭ Down load the set data to the ESC" function. Set data cannot be written to the ESC with only parameter setting.

① Selection of battery type

SELECT BATTERY
LiPo ± Air
Setting range: LiPo, NiCd
Default: LiPo

Select power battery type to use with INC(+) and DEC(-) buttons.

※ When the battery type is changed, "CUT OFF VOLTAGE" and "CUT OFF TYPE" parameters are changed.

② Setting of cut off voltage

CUT OFF VOLTAGE
Auto ± Air
Setting range: Auto, 4.5~50V
Default: Auto

Set the cut off voltage according to the battery to use with INC(+) and DEC(-) buttons.

※ With LiPo in Auto mode, the ESC cuts off at 3V per cell. In case of NiCd, the ESC cuts off at total 12V.

③ Selection of cut off type

CUT OFF TYPE
Soft Off ± Air
Setting range: Soft off, Hard off
Default: Soft off

Select the cut-off method when battery voltage drops to the set cut-off voltage.

④ Selection of motor rotating direction

MOTOR DIRECTION
Normal ± Air
Setting range: Normal, Reverse
Default: Normal

Select motor rotating direction.

※ If the direction is reverse, change the mode.

※ Direction can be changed by changing connection of the motor.

⑤ Setting of advance timing

ADVANCE TIMING
14 ± Air
Setting range: 0~25°
Default: 14°

The following range of values is recommended.

0~10° for in-runner motors

14~25° for out-runner motors

⑥ Setting of acceleration

ACCELERATION
Normal ± Air
Setting range: Lowest/Low/Normal/High/Highest
Slow ⇄ Fast

Default: Normal

Set how fast the ESC runs up to maximum speed using INC(+) and DEC(-) buttons. (Delay function) Usually this function is set when ON/OFF is done with switch.

⑦ Setting of start power

START POWER
Normal ± Air
Setting range: Lowest/Low/Normal/High/Highest
(Power small) ⇄ (Power large)

Default: Normal

Set the power (torque) level of the motor starting up.

※ When used in a helicopter model, the value should be small to avoid premature gear wear.

⑧ Selection of air brake type

AIR BRAKE TYPE
Normal ± Air
Setting range: Slow/Normal/Fast or Value 5-100%
Slow ⇄ Fast

Default: Normal

With model type AIR, adjust the air brake effect. Select to stop the motor gradually or suddenly with INC(+) and DEC(-) buttons.

※ With 100% motor stops suddenly.

⑨ Air brake ON/OFF

ABRAKE ON/OFF
Off ± Air
Setting range: On/Off
Default: Off

Select air brake ON or OFF.

⑩ Setting of motor pole number

MOTOR POLE NUM
14 Pole ± Air
Setting range: 2~36 poles
Default: 14

Change the value according to the motor to use.

※ This setting is required to indicate actual RPM.

⑪ Setting of gear ratio

GEAR RATIO
1.0 : 1 ± Air
Setting range: 1.0:1 ~ 25.0:1
Default: 1.0:1